

## VLT12 B/N/W

## VLT24 B/N/W

Installatie






Installation

Installation

Installation

Instalación

Installazione



Afmetingen


Dimensions

Abmessungen

Dimensions

Dimensiones



Dimensioni



**Aansluitschema**  
**Schéma de raccordement**

**Wiring diagram**  
**Esquema de conexiones**

**Anschlusskizze**  
**Schema di collegamento**



|   |                 |              |               |                         |                        |                         |
|---|-----------------|--------------|---------------|-------------------------|------------------------|-------------------------|
| 1 | Meter           | Gauge        | Anzeiger      | Indicateur              | Indicador              | Indicatore              |
| 2 | Contactslot     | Key switch   | Zündschloss   | Contacteur d'allumage   | Contacto               | Contatto con la chiave  |
| 3 | Lichtschakelaar | Light Switch | Lichtschalter | Interruteur d'éclairage | Interrupitor de la luz | Interruttore della luce |
| A | geel            | yellow       | gelb          | jaune                   | amarillo               | giallo                  |
| B | rood            | red          | rot           | rouge                   | rojo                   | rosso                   |
| 4 | Zekering        | Fuse         | Sicherung     | Fusible                 | Fusible                | Fusibile                |
| 5 | Accu            | Battery      | Batterie      | Batterie                | Batería                | Batteria                |

Een tweede instrument kan direct parallel aan het eerste instrument worden aangesloten.

A second instrument can be connected in parallel with the first instrument.

Ein zweites Instrument kann direkt parallel an das erste Instrument angeschlossen werden.

Un deuxième instrument peut être branché directement en parallèle au premier instrument.

Es posible conectar un segundo instrumento paralelamente al primer instrumento.

Al primo contagiri può essere collegato in parallelo un secondo strumento.



Havenstraat 11 - 3115 HC Schiedam - The Netherlands  
Tel.: +31 (0)88 4884700 - sales@vetus.com - www.vetus.com